

Nº	Marca/Modelo/Versão	Modelo de Motor	Ano / Modelo	RPM Ensaio Ruído	Limite Ruído	OBS
1	I/LEXUS/CT200H	2ZR-FXE	a partir de 2013	2500	73.4	Motor 1.8L
2	I/LEXUS/CT200H/ F SPORT	2ZR-FXE	a partir de 2013	2500	73.4	Motor 1.8L
3	I/LEXUS/ES300	1MZ-FE	a partir de 2000	4350	80.0	Motor 3.0L - V6
4	I/LEXUS/ES330	3MZ-FE	2004	4200	79.4	Motor 3.3L - V6
5	I/LEXUS/ES350	2GR-FE	2006 a 2012	4650	84.8	Motor 3.5L - V6
6	I/LEXUS/ES350	2GR-FE	a partir de 2013	4650	80.3	Motor 3.5L - V6
7	I/LEXUS/IS250	4GR-FSE	a partir de 2013	4800	82.7	Motor 2.5L - V6
8	I/LEXUS/IS250/ F SPORT	4GR-FSE	a partir de 2013	4800	82.7	Motor 2.5L - V6
9	I/LEXUS/IS 300	3GR-FE	a partir de 2011	4650	81.2	Motor 3.0L - V6
10	I/LEXUS/LS400	1UZ-FE	a partir de 2000	4050	81.0	Motor 4.0L - V8
11	I/LEXUS/LS430	3UZ-FE	2001 a 2003	4200	79.0	Motor 4.3L - V8
12	I/LEXUS/LS430	3UZ-FE	a partir de 2004	4200	79.0	Motor 4.3L - V8
13	I/LEXUS/LS460	1UR-FE	2000 a 2006	4800	81.0	Motor 4.6L - V8
14	I/LEXUS/LS460	1UR-FE	a partir de 2007	4800	81.3	Motor 4.6L - V8
15	I/LEXUS/LS460 L	1UR-FE	a partir de 2012	4800	81.3	Motor 4.6L - V8
16	I/LEXUS/LS600HL	2UR-FSE	2008	2500	79.6	Motor 5.0L - V8
17	I/LEXUS/RX350	2GR-FE	a partir de 2012	4650	85.2	Motor 3.5L - V6
18	I/LEXUS/RX350/ F SPORT	2GR-FE	a partir de 2012	4650	85.2	Motor 3.5L - V6
19	I/TOYOTA/CAMRY/ LE	1MZ-FE	a partir de 2000	4350	80.6	Motor 3.0L - V6
20	I/TOYOTA/CAMRY/ LE	2AZ-FE	a partir de 2003	4350	80.6	Motor 2.4L
21	I/TOYOTA/CAMRY/ XLE	1MZ-FE	2000 a 2001	5200	78.9	Motor 3.0L - V6
22	I/TOYOTA/CAMRY/ XLE	1MZ-FE	a partir de 2002	3975	77.7	Motor 3.0L - V6
23	I/TOYOTA/CAMRY/ XLE	2GR-FE	2006 a 2011	4650	84.8	Motor 3.5L - V6
24	I/TOYOTA/CAMRY/ XLE	2GR-FE	a partir de 2012	4650	80.4	Motor 3.5L - V6
25	I/TOYOTA/HILUX/ 2CDR DX	3RZ-FE	a partir de 1998	3600	87.5	Motor 2.7L
26	I/TOYOTA/HILUX/ 2CDR SRV	3RZ-FE	a partir de 1998	3600	87.5	Motor 2.7L
27	I/TOYOTA/HILUX/ 2CSR DX	3RZ-FE	a partir de 1998	3600	87.5	Motor 2.7L
28	I/TOYOTA/HILUX/ 2CSR SRV	3RZ-FE	a partir de 1998	3600	87.5	Motor 2.7L
29	I/TOYOTA/HILUX/ CD4X2 SR (A/T)	2TR-FBE	a partir de 2011	3900	86.1	Motor 2.7L
30	I/TOYOTA/HILUX/ CD4X2 SR (A/T)	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
31	I/TOYOTA/HILUX/ CD4X2 SR (M/T)	2TR-FBE	a partir de 2011	3900	86.1	Motor 2.7L
32	I/TOYOTA/HILUX/ CD4X2 SR (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
33	I/TOYOTA/HILUX/ CD4X2 SRV (A/T)	2TR-FBE	a partir de 2011	3900	86.1	Motor 2.7L
34	I/TOYOTA/HILUX/ CD4X2 SRV (A/T)	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
35	I/TOYOTA/HILUX/ CD4X2 SRV (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
36	I/TOYOTA/HILUX/ CD4X2 STD (M/T)	2TR-FBE	a partir de 2011	3900	86.1	Motor 2.7L
37	I/TOYOTA/HILUX/ CD4X2SR (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
38	I/TOYOTA/HILUX/ CD4X2SRAT	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
39	I/TOYOTA/HILUX/ CD4X4 SR (A/T)	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
40	I/TOYOTA/HILUX/ CD4X4 SR (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
41	I/TOYOTA/HILUX/ CD4X4 SRV	1GR-FE	a partir de 2009	3900	84.0	Motor 4.0L - V6
42	I/TOYOTA/HILUX/ CD4X4 SRV (A/T)	2TR-FBE	a partir de 2011	3900	85.4	Motor 2.7L
43	I/TOYOTA/HILUX/ CD4X4 SRV (A/T)	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
44	I/TOYOTA/HILUX/ CD4X4 SRV (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
45	I/TOYOTA/HILUX/ CD4X4 STD (A/T)	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
46	I/TOYOTA/HILUX/ CD4X4 STD (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
47	I/TOYOTA/HILUX/ CS4X2 STD (MT)	2TR-FBE	a partir de 2011	3900	86.1	Motor 2.7L
48	I/TOYOTA/HILUX/ CS4X4 (A/T)	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
49	I/TOYOTA/HILUX/ CS4X4 (M/T)	2TR-FE	2009 a 2010	4500	88.0	Motor 2.7L
50	I/TOYOTA/HILUX/ CS4X4CHAS	2TR-FE	2009 a 2010	4500	84.0	Motor 2.7L
51	I/TOYOTA/HILUX/ SW4	3RZ-FE	a partir de 1996	4800	90.0	Motor 2.7L
52	I/TOYOTA/HILUX/ SW4 4X2 SR (A/T)	2TR-FE	2009 a 2010	4500	89.0	Motor 2.7L
53	I/TOYOTA/HILUX/ SW4 4X2 SR (M/T)	2TR-FE	2009 a 2010	4500	89.0	Motor 2.7L
54	I/TOYOTA/HILUX/ SW4 4X2SR (A/T)	2TR-FBE	a partir de 2011	3900	86.2	Motor 2.7L

Nº	Marca/Modelo/Versão	Modelo de Motor	Ano / Modelo	RPM Ensaio Ruído	Limite Ruído	OBS
55	I/TOYOTA/HILUX/ SW4 4X2SR (M/T)	2TR-FBE	a partir de 2011	3900	86.2	Motor 2.7L
56	I/TOYOTA/HILUX/ SW4 SRV4X4	1GR-FE	a partir de 2009	3900	84.0	Motor 4.0L - V6
57	I/TOYOTA/HILUX/ SW4 V6	5VZ-FE	a partir de 1996	3600	86.1	Motor 3.4L - V6
58	I/TOYOTA/PASEO	5E-FE	a partir de 1996	4050	83.3	Motor 1.5L
59	I/TOYOTA/PREVIEW/ GL	2AZ-FE	a partir de 2009	4500	91.8	Motor 2.4L
60	I/TOYOTA/PRIUS	2ZR-FXE	a partir de 2012	2500	77.5	Motor 1.8L
61	I/TOYOTA/RAV4	1AZ-FE	1999	4800	80.7	Motor 2.0L
62	I/TOYOTA/RAV4	2AZ-FE	a partir de 2006	4650	85.7	Motor 2.4L
63	I/TOYOTA/RAV4 (A/T)	1AZ-FE	2000 a 2003	4500	88.4	Motor 2.0L
64	I/TOYOTA/RAV4 (A/T)	1AZ-FE	2004 a 2005	4500	88.5	Motor 2.0L
65	I/TOYOTA/RAV4 (M/T)	1AZ-FE	2000 a 2003	4500	90.7	Motor 2.0L
66	I/TOYOTA/RAV4 (M/T)	1AZ-FE	2004 a 2005	4500	89.8	Motor 2.0L
67	I/TOYOTA/RAV4/ 4X2	2AZ-FE	a partir de 2010	4650	85.7	Motor 2.4L
68	I/TOYOTA/RAV4/ 20L 4X2	3ZR-FE	a partir de 2013	4650	87.2	Motor 2.0L
69	I/TOYOTA/RAV4/ 20L 4X4	3ZR-FE	a partir de 2013	4650	87.2	Motor 2.0L
70	I/TOYOTA/RAV4/ 25L 4X4	2AR-FE	a partir de 2013	4500	87.4	Motor 2.5L
71	I/TOYOTA/RAV4/ 4X2 20L (CVT)	3ZR-FE	a partir de 2014	4650	87.2	Motor 2.0L
72	IMP/LEXUS/ES300	1MZ-FE	1997 a 1999	4350	80.0	Motor 3.0L - V6
73	IMP/LEXUS/LS400	1UZ-FE	1997 a 1999	4425	81.9	Motor 4.0L - V8
74	IMP/TOYOTA/CAMRY/ LE	5S-FE	1995 a 1997	3900	80.3	Motor 2.2L
75	IMP/TOYOTA/CAMRY/ LE V6	1MZ-FE	1998 a 2001	4050	78.9	Motor 3.0L - V6
76	IMP/TOYOTA/CAMRY/ XLE	1MZ-FE	1997 a 2000	4050	78.9	Motor 3.0L - V6
77	IMP/TOYOTA/COROLLA/ DX	4A-FE	1993 a 1995	4350	89.8	Motor 1.6L
78	IMP/TOYOTA/COROLLA/ DX	4A-FE	a partir de 1996	4200	92.3	Motor 1.6L
79	IMP/TOYOTA/COROLLA/ GLI	4A-FE	a partir de 1997	4500	82.5	Motor 1.6L
80	IMP/TOYOTA/COROLLA/ GLI18	7A-FE	a partir de 1998	3900	82.7	Motor 1.8L
81	IMP/TOYOTA/COROLLA/ GX	7A-FE	a partir de 1998	3900	82.7	Motor 1.8L
82	IMP/TOYOTA/COROLLA/ GXI	7A-FE	a partir de 1998	3900	82.7	Motor 1.8L
83	IMP/TOYOTA/COROLLA/ LE	7A-FE	a partir de 1993	4200	92.2	Motor 1.8L
84	IMP/TOYOTA/COROLLA/ WG	7A-FE	a partir de 1993	4200	92.2	Motor 1.8L
85	IMP/TOYOTA/COROLLA/ WGXLI	4A-FE	1997 a 2000	4500	82.5	Motor 1.6L
86	IMP/TOYOTA/COROLLA/ WGXLI	7A-FE	a partir de 1998	3900	82.7	Motor 1.8L
87	IMP/TOYOTA/COROLLA/ XLI	4A-FE	a partir de 1997	4500	82.5	Motor 1.6L
88	IMP/TOYOTA/COROLLA/ XLI18	7A-FE	a partir de 1998	3900	82.7	Motor 1.8L
89	IMP/TOYOTA/CORONA	3S-SE	1997	4050	83.1	Motor 2.0L
90	IMP/TOYOTA/CORONA/ GLI	3S-FE	a partir de 1996	4050	83.1	Motor 2.0L
91	IMP/TOYOTA/HILUX/ SW4	3RZ-FE	1994 a 1995	4800	90.0	Motor 2.7L
92	IMP/TOYOTA/HILUX/ SW4 V6	5VZ-FE	1994 a 1995	3600	86.1	Motor 3.4L - V6
93	IMP/TOYOTA/PASSEO	5E-FE	1994 a 1995	4800	90.4	Motor 1.5L
94	IMP/TOYOTA/PREVIEW/ LE	2TZ-FE	1993 a 2008	3750	91.8	Motor 2.5L
95	IMP/TOYOTA/RAV4	3S-FE	1998/1999	4050	83.0	Motor 2.0L
96	TOYOTA/COROLLA/ ALTIS20FX (A/T)	3ZR-FBE	a partir de 2010	4350	88.1	Motor 2.0L
97	TOYOTA/COROLLA/ GLI FLEX (A/T)	2ZR-FBE	a partir de 2011	4500	87.2	Motor 1.8L
98	TOYOTA/COROLLA/ GLI FLEX (M/T)	2ZR-FBE	a partir de 2011	4500	87.7	Motor 1.8L
99	TOYOTA/COROLLA/ GLI18FLEX (A/T)	1ZZ-FBE	a partir de 2009	4500	85.6	Motor 1.8L
100	TOYOTA/COROLLA/ GLI18FLEX (M/T)	1ZZ-FBE	a partir de 2009	4500	86.5	Motor 1.8L
101	TOYOTA/COROLLA/ S 16 VVT (A/T)	3ZZ-FBE	a partir de 2008	4500	87.1	Motor 1.6L
102	TOYOTA/COROLLA/ S 18VVT (A/T)	1ZZ-FE	a partir de 2006	4500	88.6	Motor 1.8L
103	TOYOTA/COROLLA/ S 18VVT (M/T)	1ZZ-FE	a partir de 2006	4500	90.1	Motor 1.8L
104	TOYOTA/COROLLA/ S18FLEX (A/T)	1ZZ-FBE	a partir de 2008	4500	85.6	Motor 1.8L
105	TOYOTA/COROLLA/ S18FLEX (M/T)	1ZZ-FBE	a partir de 2008	4500	86.5	Motor 1.8L
106	TOYOTA/COROLLA/ SE-G	7A-FE	1998 a 2001	4350	83.3	Motor 1.8L
107	TOYOTA/COROLLA/ SEG18FLEX (A/T)	1ZZ-FBE	2007	4500	87.0	Motor 1.8L

Nº	Marca/Modelo/Versão	Modelo de Motor	Ano / Modelo	RPM Ensaio Ruído	Limite Ruído	OBS
108	TOYOTA/COROLLA/ SEG18FLEX (A/T)	1ZZ-FBE	a partir de 2008	4500	85.6	Motor 1.8L
109	TOYOTA/COROLLA/ SEG18FLEX (M/T)	1ZZ-FBE	2007	4500	88.9	Motor 1.8L
110	TOYOTA/COROLLA/ SEG18FLEX (M/T)	1ZZ-FBE	a partir de 2008	4500	86.5	Motor 1.8L
111	TOYOTA/COROLLA/ SEG18VVT (A/T)	1ZZ-FE	a partir de 2002	4500	88.6	Motor 1.8L
112	TOYOTA/COROLLA/ SEG18VVT (M/T)	1ZZ-FE	a partir de 2002	4500	90.1	Motor 1.8L
113	TOYOTA/COROLLA/ SEG20FLEX (A/T)	3ZR-FBE	a partir de 2010	4350	88.1	Motor 2.0L
114	TOYOTA/COROLLA/ XEI	7A-FE	1998 a 2001	4350	83.3	Motor 1.8L
115	TOYOTA/COROLLA/ XEI18FLEX (A/T)	1ZZ-FBE	2007	4500	87.0	Motor 1.8L
116	TOYOTA/COROLLA/ XEI18FLEX (A/T)	1ZZ-FBE	a partir de 2008	4500	85.6	Motor 1.8L
117	TOYOTA/COROLLA/ XEI18FLEX (M/T)	1ZZ-FBE	2007	4500	88.9	Motor 1.8L
118	TOYOTA/COROLLA/ XEI18FLEX (M/T)	1ZZ-FBE	a partir de 2008	4500	86.5	Motor 1.8L
119	TOYOTA/COROLLA/ XEI18VVT (A/T)	1ZZ-FE	a partir de 2002	4500	88.6	Motor 1.8L
120	TOYOTA/COROLLA/ XEI18VVT (M/T)	1ZZ-FE	a partir de 2002	4500	90.1	Motor 1.8L
121	TOYOTA/COROLLA/ XEI20FLEX (A/T)	3ZR-FBE	a partir de 2010	4350	88.1	Motor 2.0L
122	TOYOTA/COROLLA/ XLI	7A-FE	1998 a 2001	4350	83.3	Motor 1.8L
123	TOYOTA/COROLLA/ XLI FLEX (A/T)	2ZR-FBE	a partir de 2011	4500	87.2	Motor 1.8L
124	TOYOTA/COROLLA/ XLI FLEX (M/T)	2ZR-FBE	a partir de 2011	4500	87.7	Motor 1.8L
125	TOYOTA/COROLLA/ XLI16VVT (A/T)	3ZZ-FE	a partir de 2002	4500	85.6	Motor 1.6L
126	TOYOTA/COROLLA/ XLI16VVT (A/T)	3ZZ-FBE	a partir de 2008	4500	87.1	Motor 1.6L
127	TOYOTA/COROLLA/ XLI16VVT (M/T)	3ZZ-FE	a partir de 2002	4500	86.0	Motor 1.6L
128	TOYOTA/COROLLA/ XLI18FLEX (A/T)	1ZZ-FBE	2007	4500	87.0	Motor 1.8L
129	TOYOTA/COROLLA/ XLI18FLEX (A/T)	1ZZ-FBE	a partir de 2008	4500	85.6	Motor 1.8L
130	TOYOTA/COROLLA/ XLI18FLEX (M/T)	1ZZ-FBE	2007	4500	88.9	Motor 1.8L
131	TOYOTA/COROLLA/ XLI18FLEX (M/T)	1ZZ-FBE	a partir de 2008	4500	86.5	Motor 1.8L
132	TOYOTA/COROLLA/ XRS FLEX (A/T)	3ZR-FBE	a partir de 2012	4350	88.1	Motor 2.0L
133	TOYOTA/COROLLA/ ALTISFLEX (CVT)	3ZR-FBE	a partir de 2014	4350	86.8	Motor 2.0L
134	TOYOTA/COROLLA/ XEI20FLEX (CVT)	3ZR-FBE	a partir de 2014	4350	86.8	Motor 2.0L
135	TOYOTA/COROLLA/ GLI18 CVT (CVT)	2ZR-FBE	a partir de 2014	4500	86.1	Motor 1.8L
136	TOYOTA/COROLLA/ GLI18FLEX (MT)	2ZR-FBE	a partir de 2014	4500	86.5	Motor 1.8L
137	TOYOTA/ETIOS HB	1NR-FBE	a partir de 2012	4200	82.1	Motor 1.3L
138	TOYOTA/ETIOS HB/ CROSS	2NR-FBE	a partir de 2013	4200	82.3	Motor 1.5L
139	TOYOTA/ETIOS HB/ X	1NR-FBE	a partir de 2012	4200	82.1	Motor 1.3L
140	TOYOTA/ETIOS HB/ XLS	2NR-FBE	a partir de 2012	4200	82.3	Motor 1.5L
141	TOYOTA/ETIOS HB/ XS	1NR-FBE	a partir de 2012	4200	82.1	Motor 1.3L
142	TOYOTA/ETIOS HB/ XS	2NR-FBE	a partir de 2013	4200	82.3	Motor 1.5L
143	TOYOTA/ETIOS HB/ XS 15	2NR-FBE	a partir de 2013	4200	82.3	Motor 1.5L
144	TOYOTA/ETIOS HB/ PLATINUM (M/T)	2NR-FBE	a partir de 2014	4200	82.3	Motor 1.5L
145	TOYOTA/ETIOS SD/ X	2NR-FBE	a partir de 2012	4200	82.3	Motor 1.5L
146	TOYOTA/ETIOS SD/ XLS	2NR-FBE	a partir de 2012	4200	82.3	Motor 1.5L
147	TOYOTA/ETIOS SD/ XS	2NR-FBE	a partir de 2012	4200	82.3	Motor 1.5L
148	TOYOTA/ETIOS SD/ PLATINUM (M/T)	2NR-FBE	a partir de 2014	4200	82.3	Motor 1.5L
149	TOYOTA/FIELDER (A/T)	1ZZ-FE	a partir de 2004	4500	88.6	Motor 1.8L
150	TOYOTA/FIELDER (M/T)	1ZZ-FE	a partir de 2004	4500	90.1	Motor 1.8L
151	TOYOTA/FIELDER/ S18VVT (A/T)	1ZZ-FE	2006	4500	88.6	Motor 1.8L
152	TOYOTA/FIELDER/ S18VVT (M/T)	1ZZ-FE	2006	4500	90.1	Motor 1.8L
153	TOYOTA/FIELDER/ SEG18FLEX (A/T)	1ZZ-FBE	a partir de 2007	4500	87.0	Motor 1.8L
154	TOYOTA/FIELDER/ SEG18FLEX (M/T)	1ZZ-FBE	a partir de 2007	4500	88.9	Motor 1.8L
155	TOYOTA/FIELDER/ XEI18FLEX (A/T)	1ZZ-FBE	a partir de 2007	4500	87.0	Motor 1.8L
156	TOYOTA/FIELDER/ XEI18FLEX (M/T)	1ZZ-FBE	a partir de 2007	4500	88.9	Motor 1.8L



Nº	Marca/Modelo/Versão	Marca/Modelo de Motor	rpm corte min	rpm corte	rpm corte max	rpm M L min	rpm M L	rpm M L max	Índice Fumaça aceleração livre Altitudes até 350m	Índice Fumaça aceleração livre Altitudes acima de 350m	rpm Ens Ruído	Lim Ruído	OBS (*)
1	I/TOYOTA/HILUX/ 2CDL DX	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2001
2	I/TOYOTA/HILUX/ 2CDL SRV	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2001
3	I/TOYOTA/HILUX/ 2CSL	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2001
4	I/TOYOTA/HILUX/ 4CDK SR	Toyota / 1KZ-TE / Motor 3.0L	4450	4600	4750	650	700	750	1.23	1.66	3600	96.6	2001
5	I/TOYOTA/HILUX/ 4CDK SRV	Toyota / 1KZ-TE / Motor 3.0L	4450	4600	4750	650	700	750	1.23	1.66	3600	96.6	2001
6	I/TOYOTA/HILUX/ 4CDL DX	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2001
7	I/TOYOTA/HILUX/ 4CDL SR	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2004
8	I/TOYOTA/HILUX/ 4CDL SRV	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2001
9	I/TOYOTA/HILUX/ 4CSL DX	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2001
10	I/TOYOTA/HILUX/ CD4X2 (M/T)	Toyota / 2KD-FTV / Motor 2.5L	4450	4600	4750	700	750	800	0.69	1.19	2700	84.0	2005 a 2011
11	I/TOYOTA/HILUX/ CD4X2 SR (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	82.2	2005 a 2011
12	I/TOYOTA/HILUX/ CD4X2 SR (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	84.0	2005 a 2011
13	I/TOYOTA/HILUX/ CD4X2 SRV (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	82.2	2005 a 2011
14	I/TOYOTA/HILUX/ CD4X2 SRV (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	84.0	2005 a 2011
15	I/TOYOTA/HILUX/ CD4X4 (M/T)	Toyota / 2KD-FTV / Motor 2.5L	4450	4600	4750	700	750	800	0.69	1.19	2700	84.0	2005 a 2011
16	I/TOYOTA/HILUX/ CD4X4 SR (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	82.2	2005 a 2011
17	I/TOYOTA/HILUX/ CD4X4 SR (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.9	a partir de 2012
18	I/TOYOTA/HILUX/ CD4X4 SR (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	84.0	2005 a 2011
19	I/TOYOTA/HILUX/ CD4X4 SR (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.8	a partir de 2012
20	I/TOYOTA/HILUX/ CD4X4 SRV (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	82.2	2005 a 2011
21	I/TOYOTA/HILUX/ CD4X4 SRV (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.9	a partir de 2012
22	I/TOYOTA/HILUX/ CD4X4 LE (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.9	a partir de 2014
23	I/TOYOTA/HILUX/ CD4X4 SRV (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	84.0	2005 a 2011
24	I/TOYOTA/HILUX/ CD4X4 SRV (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.8	a partir de 2012
25	I/TOYOTA/HILUX/ CD4X4 STD (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.8	a partir de 2012
26	I/TOYOTA/HILUX/ CS4X2 (MT)	Toyota / 2KD-FTV / Motor 2.5L	4450	4600	4750	700	750	800	0.69	1.19	2700	84.0	2005 a 2011
27	I/TOYOTA/HILUX/ CS4X2CHAS (M/T)	Toyota / 2KD-FTV / Motor 2.5L	4450	4600	4750	700	750	800	0.69	1.19	2700	84.0	2005 a 2011
28	I/TOYOTA/HILUX/ CS4X4 (M/T)	Toyota / 2KD-FTV / Motor 2.5L	4450	4600	4750	700	750	800	0.69	1.19	2700	84.0	2005 a 2011
29	I/TOYOTA/HILUX/ CS4X4 (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.8	a partir de 2012
30	I/TOYOTA/HILUX/ CS4X4CHAS (M/T)	Toyota / 2KD-FTV / Motor 2.5L	4450	4600	4750	700	750	800	0.69	1.19	2700	84.0	2005 a 2011
31	I/TOYOTA/HILUX/ CS4X4CHAS (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.8	a partir de 2012
32	I/TOYOTA/HILUX/ DX CHASSI	Toyota / 5L / Motor 3.0L	4270	4400	4530	650	700	750	1.28	1.92	2850	89.4	2002
33	I/TOYOTA/HILUX/ SW4	Toyota / 1KZ-TE / Motor 3.0L	4450	4600	4750	650	700	750	1.23	1.66	3600	96.6	2000
34	I/TOYOTA/HILUX/ SW4 4X4SR (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.9	a partir de 2012
35	I/TOYOTA/HILUX/ SW4 D	Toyota / 1KZ-T / Motor 3.0L	4450	4600	4750	650	700	750	1.23	1.66	2700	97.4	1998
36	I/TOYOTA/HILUX/SW4 SRV4X4 (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	82.2	2005 a 2011
37	I/TOYOTA/HILUX/SW4 SRV4X4 (A/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2700	80.8	a partir de 2012
38	I/TOYOTA/HILUX/SW4 SRV4X4 (M/T)	Toyota / 1KD-FTV / Motor 3.0L	4450	4600	4750	700	750	800	0.69	1.19	2550	84.0	2005 a 2011
39	I/TOYOTA/LAND CRUISER PR	Toyota / 1KZ-TE / Motor 3.0L	4450	4600	4750	700	750	800	0.92	1.24	2700	86.7	a partir de 2003
40	IMP/TOYOTA/HILUX/ 2CD	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
41	IMP/TOYOTA/HILUX/ 2CD	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
42	IMP/TOYOTA/HILUX/ 2CD DLX	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
43	IMP/TOYOTA/HILUX/ 2CD DLX	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
44	IMP/TOYOTA/HILUX/ 2CS	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
45	IMP/TOYOTA/HILUX/ 2CS	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
46	IMP/TOYOTA/HILUX/ 2CS DLX	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
47	IMP/TOYOTA/HILUX/ 2CS DLX	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
48	IMP/TOYOTA/HILUX/ 4CD DLX	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
49	IMP/TOYOTA/HILUX/ 4CD DLX	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
50	IMP/TOYOTA/HILUX/ 4CD SR5	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
51	IMP/TOYOTA/HILUX/ 4CD SR5	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
52	IMP/TOYOTA/HILUX/ 4CS	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
53	IMP/TOYOTA/HILUX/ 4CS	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
54	IMP/TOYOTA/HILUX/ 4CS SR5	Toyota / 3L / Motor 2.8L	4335	4400	4465	650	700	750	1.14	1.71	3800	99.4	1997 a 2000
55	IMP/TOYOTA/HILUX/ 4CS SR5	Toyota / 3L / Motor 2.8L	4250	4400	4550	650	700	750	1.14	1.71	3800	99.4	a partir de 2000
56	TOYOTA/BAND/ BJ50 L	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
57	TOYOTA/BAND/ BJ50 L	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
58	TOYOTA/BAND/ BJ50 LV	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
59	TOYOTA/BAND/ BJ50 LV	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
60	TOYOTA/BAND/ BJ50 LVB	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
61	TOYOTA/BAND/ BJ50 LVB	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
62	TOYOTA/BAND/ BJ55LP 2BL	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
63	TOYOTA/BAND/ BJ55LP 2BL	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
64	TOYOTA/BAND/ BJ55LP 2BL4	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	1999
65	TOYOTA/BAND/ BJ55LP B	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
66	TOYOTA/BAND/ BJ55LP B	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
67	TOYOTA/BAND/ BJ55LP B3	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
68	TOYOTA/BAND/ BJ55LP B3	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
69	TOYOTA/BAND/ BJ55LP BL	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
70	TOYOTA/BAND/ BJ55LP BL	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
71	TOYOTA/BAND/ BJ55LP BL3	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
72	TOYOTA/BAND/ BJ55LP BL3	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996
73	TOYOTA/BAND/ BJ55LP BL3S	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	92.8	1994 a 1995
74	TOYOTA/BAND/ BJ55LP BL3S	Toyota / 14B / Motor 3.7L	4000	4150	4300	750	800	850	1.28	1.92	3400	90.6	a partir de 1996

\*Ano modelo